SHERRILL FURNITURE

3 Series Design Your Own

Create Your Own Upholstery with the New 3 Series

Design custom upholstery that's uniquely yours. Start by choosing from four arm styles, each available in either a High Back or Low Back profile. Then personalize your piece with four back options and your choice of a Dressmaker Skirt or Wood Leg base. Finish your design with one of three welt options to create a custom look that perfectly fits your style.

3					
Step 1: Series	Step 2: Frame	Step 3: Arm	Step 4: Back	Step 5: Base	Step 6: Welt

Standards:
Seat Depth: 21″
Seat Height: 19″
Arm Height: 25″



1 3 Series

2 Select Your Frame Style

*SW Swivel Option Available on 01-Chair with Dressmaker Skirt Option
**Special One Piece Bench Seat Option Available on Sofas & Loveat (upcharge)

00 - Ottoman
01 - Chair 36″
02 - Two Cushion 66″ Loveseat
23 - Two Cushion 78″ Sofa
33 - Three Cushion 78″ Sofa
24 - Two Cushion 91″ Sofa
34 - Three Cushion 91″ Sofa
25 - Two Cushion 104″ Sofa



* High Back Arm Style
HE - High English



* Low Back Arm Style
LE - Low English

High Back Arms will increase the overall height and depth of the frame. As the back height increases, the overall depth will also increase slightly due to the pitch of the outside back. In other words, the higher the back, the greater the overall frame height and depth. (See Dimensions on Back)

3 Select Your Arm Style

Each Arm Style is available with your choice of a H-High or L-L ow Back/Arm Profile.



HE - High English



HF - High Flair



HP - High Pleat



HT - High Track



LE - Low English



LF - Low Flair



LP - Low Pleat



LT - Low Track

Back Style Options will also affect the overall height and depth of 3 Series frames. Frames with loose back pillow options will have a greater overall depth because additional space is required to accommodate the thickness of the loose back cushion. The back cushion will also extend slightly above the back rail, which can affect the overall height of the frame.

4 Select Your Back Style



B - Box Loose



K - Knife Loose



T - Tight



U - Button (Tight)

5 Select Your Base



W - Wood Leg



D - Dressmaker

6 Select Your Welt



C - Welt Cord



F - French Seam




D - Double Needle

SHERRILL FURNITURE

3 Series Design Your Own


3											
Step 1: Series		Step 2: Frame		Step 3: Arm		Step 4: Back		Step 5: Base		Step 6: Welt	




__ 01 CHAIR




__ 00 OTTOMAN




__ 02 LOVESEAT




__ 23 SOFA




__ 33 SOFA




__ 24 SOFA



__ 34 SOFA



__ 25 SOFA



__ 35 SOFA

3 Series Options

ARM STYLES / HIGH BACK	ARM STYLES / LOW BACK	BACK	BASE	WELT
HE - High English	**LE** - Low English	**B** - Box Loose	**W** - Wood Leg	**C** - Welt Cord
HF - High Flair	**LF** - Low Flair	**K** - Kinfe Loose	**D** - Dressmaker	**F** - French Seam
HP - High Pleat	**LP** - Low Pleat	**T** - Tight Back		**N** - Double Needle
HT - High Track	**LT** - Low Track	**U** - Button Tight Back		

Approximate Dimensions :

H* W*D* Seat Depth: 21″, Seat Height: 19″ Arm Height: 25″
Sofas Standard with 2 - 21″ x 21″ Throw Pillow

***Overall Depth and Height will vary with Options**

H - High Arm Styles with **B** - Box Loose & **K** - Knife Loose Backs. Approx: D 40-42″ and Frame H35-36″ (Height to top of Loose Back 37-38″)
H - High Arm Styles with **T** - Tight Back & **U**– Button Tight Back Approx: D 37-38″ and H 36-37″
L - Low Arm Styles with **B** - Box Loose & **K** - Knife Loose Backs Approx: D 37-38″ and Frame H 35-36″ (Height to top of Loose Back 35-36″)
L - Low Arm Styles with **T** - Tight Back & **U**– Button Tight Back Approx: D 33-34″ and H 29-30″



301HEKDC Chair
36W 41D 36H

3: Series
HE: High English Arm
K: Knife Loose Back

D: Dressmaker
C: Welt Cord



334LETWC Sofa
91W 34D 30H

3: Series
34: Three Cushion 91″
LE: Low English Arm

T: Tight Back
W: Wood Leg
C: Welt Cord



301HFBDC Chair
36W 40D 37H

3: Series
01: Chair
HF: High Fan Arm

B: Box Loose Back
D: Dressmaker
C: Welt Cord



334LFBDF Sofa
91W 38D 37H

3: Series
34: Three Cushion 91″
LF: Low Fan Arm

B:Box Loose Back
D: Dress Maker
F: French Seam



301LPUWC Chair
36W 34D 30H

3: Series
01: Chair
LP: Low Pleat Arm

U: Button Back (Tight)
W: Wood Leg
C: Welt Cord



324HPUC Sofa
91W 38D 36H

3: Series
24: Two Cushion 91″
HP: High Pleat Arm

U: Button Back (Tight)
D: Dressmaker
C: Welt Cord



301HTUDC Chair
36W 38D 36H

3: Series
01: Chair
HT: High Track Arm

U: Button Back (Tight)
D: Dressmaker
C: Welt Cord



324LTKWC Sofa
91W 38D 36H

3: Series
24: Two Cushion 91″
LT: Low Track Arm

K: Knife Loose Back
W: Wood Leg
C: Welt Cord